


HOOD, STEERING WHEEL, LIGHTS & WINDSHIELD WIPER CONTROLS

Continued on back

Get to know your truck by learning these everyday controls that make your truck uniquely Mack.


OPENING THE HOOD

1. Reaching under the grille above the bumper, pull the paddle toward the driver's side to disengage the locking tab from the hood latch.
2. Firmly grasp the Bulldog and pull toward you slowly. You will hear a soft clang as the hood locking mechanism slides into place.



CLOSING THE HOOD

1. Release the safety latch by moving it to the up position. You **MUST** release the latch for the hood to close.
2. Firmly grasp the Bulldog and slide the hood away from you into the closed position.



MAEK®




Watch a demo at:
MackTrucks.com/KnowYourMack

**Hood, Steering Wheel, Lights &
Windshield Wiper Controls**


HOOD, STEERING WHEEL, LIGHTS & WINDSHIELD WIPER CONTROLS

Get to know your truck by learning these everyday controls that make your truck uniquely Mack®.



STALK CONTROLS

- Move whole stalk up or down to activate self-canceling turn signals.
- Turn windshield wipers on and select wiper speed with the scroll ring in the middle of the control stalk.
- Activate wiper fluid by moving and holding the selector band forward.
- Turn on high beam headlights by rotating the end of the stalk forward in the direction of the symbol; activate momentary high beam flash by rotating the end of the stalk backwards in the direction of the symbol.
- Activate marker interrupt by pressing the button at the end of the stalk.



ADJUSTING THE STEERING COLUMN

To adjust the steering wheel to a different vertical position, fully depress the foot pedal located at the left kick panel (1) and continue to hold the pedal down until you have finished adjusting.